

LEAKING FUEL TANK TAP

Recommended solution for a leak in the tap (fig 1) of your fuel tank:

- Dismantle the tap (fig 2);
- Clean the cone of the fuel tank (fig 3) and the cone of the tap (fig 4);
- Apply a thin layer of silicone grease (laboratory product) to the cone of the tap (fig 4);
- Assemble all parts and gently screw the nut on without using excess force;
- Never screw more tightly to deal with a leak; the more force you apply, the more you will damage the surface of the cone and increase the leak;
- To ensure no particles get into your fuel, please filter before filling up the tank.



Fig 1



Fig 2



Fig 3




Fig 4